

CQB Compensator Installation Instructions:

Ensure the weapon is not loaded and is on SAFE prior to working on your weapon. Place your upper receiver into a vise block and ensure everything is secured. Install the included crush washer with the flared side of the crush washer facing the barrel shoulder. Thread the muzzle device on the rifle until it is hand tight against the crush washer.

Using a strap wrench, turn the CQB Comp 1/4 to 1/2 turn in order to crush the washer and secure the muzzle device. NOTE: Timing of the CQB Comp is not required as there is no specific top or bottom to this device.

PRC Compensator Installation Instructions:

Ensure the weapon is not loaded and is on SAFE prior to working on your weapon. Place your upper receiver into a vise block and ensure everything is secured. Please double check that the thread pitch & caliber of this compensator matches your barrel's thread pitch prior to installing. Install the included crush washer with the flared side of the crush washer facing the barrel shoulder. Thread the muzzle device on the rifle until it is hand tight against the crush washer.

Using a 5/8" wrench, tighten the compensator until the PWS logo is centered on top of the rifle. If this requires less than a 90 degree rotation, rotate the compensator one full rotation plus the 90 degrees until timed.

FSC Compensator Installation Instructions:

Ensure the weapon is not loaded and is on SAFE prior to working on your weapon. Place your upper receiver into a vise block and ensure everything is secured. Please double check that the thread pitch of this compensator matches your barrel's thread pitch prior to installing. Install the included crush washer with the flared side of the crush washer facing the barrel shoulder. Thread the muzzle device on the rifle until it is hand tight against the crush washer.

Using a 5/8" wrench, tighten the compensator until the PWS logo is centered on top of the rifle. If this requires less than a 90 degree rotation, rotate the compensator one full rotation plus the 90 degrees until timed.

JTAC Compensator Installation Instructions:

Ensure the weapon is not loaded and is on SAFE prior to working on your weapon. Place your upper receiver into a vise block and ensure everything is secured.

Thread the muzzle device onto the barrel until it reaches the bottom of the threads.

Turn the device counter-clockwise until the plunger engages the indexing hole, preventing the device from rotating. This will hold your muzzle device in place. Installation of the muzzle device is now complete.

NOTE: A red space washer can be used to combat the rattle commonly associated with AK47 muzzle devices.

PCC Compensator Installation Instructions:

Ensure the weapon is not loaded and is on SAFE prior to working on your weapon. Place your upper receiver into a vise block and ensure everything is secured. Please double check that the thread pitch of this compensator (machined onto the barrel-facing edge) matches your barrel's thread pitch prior to installing. Install the included crush washer with the flared side of the crush washer facing the barrel shoulder. Thread the muzzle device on the rifle until it is hand tight against the crush washer.

Using a 5/8" wrench, tighten the compensator until the PWS logo is centered on top of the rifle. If this requires less than a 90 degree rotation, rotate the compensator one full rotation plus the 90 degrees until timed.